

Revolutionary 2-Step Ceramic Resurface and Polish

STEP 1—DAZZLE 1



DESCRIPTION: **Dazzle 1** is a ready to use product that is the first part of a two step ceramic tile polishing process. **Dazzle 1** hones the tile and helps to clean the grout. The second step in the process, **Dazzle 2**, completes the process by imparting a high gloss to unglazed ceramic surfaces.

DIRECTIONS FOR USE: Remove all topical coatings from the floor. Cover baseboard, carpet, etc., with protective plastic and/or tape. **EQUIPMENT:** Low speed floor machine, **Apeiron's Dia-Poly Pre Polish Pad (PP)**. Wet a 25 sq. ft. (2.5 sq. m) area and apply approximately 3 oz (84 grams) of **Apeiron's Dazzle 1**. Buff into a slurry over the 25 sq. ft. (2.5 sq. m) area. Add water as necessary to maintain proper slurry consistency. Work the material slowly over the area for approximately 10 minutes. Wet vacuum and double flood rinse removing all residue. Move to the next 25 sq. ft. (2.5 sq. m) area and repeat. Overlap areas to blend. When the whole area is completed with **Dazzle 1**, move to **Apeiron's Dazzle 2** procedures. To facilitate cleanup, do not allow slurry to dry on surface.

STEP 2—DAZZLE 2



DESCRIPTION: **Dazzle 2** is the second part of a two-step ceramic tile polishing process. **Dazzle 2** will add a high gloss to properly prepared, unglazed ceramic surfaces.

DIRECTIONS FOR USE: Use **Dazzle 1** to prepare the tile prior to using **Apeiron's Dazzle 2**. Cover baseboard, carpet, etc., with protective plastic and/or tape. **EQUIPMENT:** Low speed floor machine, **Apeiron's Dia-Poly Final Polish Pad (FP)**. Wet a 25 sq. ft. (2.5 sq. m) area and apply approximately 3 oz (84 grams) of **Apeiron's Dazzle 2**. Buff into a slurry over the 25 sq. ft. (2.5 sq. m) area. Add water as necessary to maintain proper slurry consistency. Work the material slowly over the area for approximately 10 minutes. When the desired level of gloss has been reached, wet vacuum and double flood rinse removing all residue. Move to the next 25 sq. ft. (2.5 sq. m) area and repeat. Overlap areas to blend. Let dry and buff with a dry white pad to remove all remaining surface residue. To facilitate cleanup, do not allow slurry to dry on surface.

