

*Terrazzo Wall & Tub Surround
Resurfacing and Polishing Procedures*

Step 1—Scratch Removal Procedures

Thoroughly strip to remove all coatings and soap scum.

With a low speed hand held machine hone the surface with **Apeiron's OCP 3" Disk** and water.

Honing time:
Marble - 30 seconds per sq. ft. Keep wet at all times. Work 6 to 9 sq. ft. from top to bottom.

Remove the slurry and rinse with **Apeiron's Stone Wash**. Inspect to ensure scratches have been removed.



Step 2—Wet Polishing

Wet pad with water, Apply 1 oz of Apeiron's **Wet Polish** directly to pad.

Using a trigger sprayer, wet the wall, also wet the powder on the pad, this keeps the powder in place.

Buff for 30 seconds per sq. ft. Keeping the surface wet, work 6 to 9 sq. ft. from top to bottom.

Work a small area at a time. Remove slurry and wipe dry with a soft cloth. Allow stone to dry completely before applying **Stone Paste**.




Step 3— Application of Stone Paste

Apply a thin amount of **Stone Paste** with a soft cloth or pad in a circular motion.

Press firmly to push the paste into pores. Allow to dry for 5-10 minutes (*do not allow more than 10 minutes of dry time*).

When surface is completely dry, buff with a white pad until high gloss appears.

Because of its unique composition this product achieves excellent gloss & protection.



Repeat application if higher gloss is desired